

QUICK SETUP GUIDE

anchor link™
quick-connect system

Anchor™ attachment to camera lug



Anchor™ attachment to tripod plate



Anchor™ usage tips



For more information



peakdesignltd.com/tips



For additional usage tips visit peakdesignltd.com/tips


QUICK SETUP GUIDE

slide™
camera sling strap


Slide™ configurations



Slide™ adjustment: front



Slide™ adjustment: back



For additional usage tips visit peakdesignltd.com/tips

